The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.




TABLE OF CONTENTS

Index Introduction	3
ENGINE SECTION	
Alternator	7 9 11 13 15 17
GENERATOR SECTION	
Blank for Notes	333 3537 37 39 41 43 45
CONTROL SECTION	
Control, Generator Set	. 55 . 57 . 59 . 61 . 63 . 65

Index

Adapter, Generator 43,45. Alarm Module 55, Alternator 55, Ammeter - AC 55, Ammeter - DC 59, Belt, Drive 66,	68 5 57 61	Harness, Engine	59,61 63,65 39,41 13
Board, LED Lights	55	Indicator, Air Service 7	. 9 . 11
Cable, Battery Cap, Radiator Cleaner, Air - Heavy Duty Cleaner, Air - Indoor Cleaner, Air - Outdoor Contactor, Heater	19 11 7 9 21	Meter, Hour	59,61 39,41 66,67 45,47
Control, Engine	53 .57 .67 .67	Sender, Pressure - Oil	15 13 17
Element, Air Cleaner	11	Stator, Exciter	39,41 39,41 21 19
Fan, Cooling	15	Switch, Selector	55,57 13
Gauge, Pressure - Oil	61 35 5	Tachometer	13 67 . 15
		Wattmeter	55,57

Introduction

This Parts Catalog applies to the Generator Sets Listed below. The illustrations are arranged in groups of related items, and each part or assembly is identified by a Reference Number. All parts illustrated are typical, and unless otherwise mentioned in the description column the parts are interchangeable between models. Dual Part No. may be applicable; CPS are Cummins Power Systems assigned Part Numbers and CEC are the Cummins Engine Company asigned Part Numbers.

These typical illustrations are subject to change and reflect only the latest replacement parts arrangement. The Right and Left sides of the Generator Set are determined by FACING the FRONT of the Set (Engine Radiator End)

Set Data Table

ENGINE ID. No.	GEN SET ID No.	RPM RATING	BATTERY VOLTAGE
Note 1. KT19-G*# KTA19-G <u>*#</u> KTTA19-G <u>*#</u>	Note 2. ×××KT@ ×××KTA@ ×××KTT@	1800 RPM/ 1500 RPM 1800 RPM/ 1500 RPM 1800 RPM/ 1500 RPM	24 VDC 24 VDC 24 VDC

Note:1 * - Letter S for Standby, Letter C for Continious Duty applications Note:1 # - Number 1 thru 9 used to denote size varations. Note:2 x - Numbers used to denote kW ratings: eg: 230 means 230,000 watt set. Note:2 θ - Number 1 thru 9 used to denote size varations.

Electrical Data Table

LOW Y	LTAGE HIGH Y	HERTZ	WIRE	PHASE	NOTES
190/110 208/120 220/127 230/133 240/139	380/219 416/220 440/254 460/266 480/277	60 60 60 60	12 12 12 12 12	3 3 3 3 3	
190/110 200/115 208/120	380/219 400/231 416/240	5 0 50 50	12 12 12	3 3 3	

Engine Replacement Parts

The External Engine Components added or modified during the Generator Set Assembly and most General Maintance Items are identified in this Parts Catalog. For Internal Engine Parts and Components not covered herein; refer to the applicable Cummins Engine G Drive Parts Catalog.


General Information

For parts or service, contact the distributor from whom you purchased this equipment or refer to the nearest Authorized Cummins Distributor.

To avoid errors or delays in filling your parts order, always give the full MODEL, SERIAL and ID No. from the nameplate.


For handy reference, insert "YOUR" nameplate information is the spaces below.


Cummins		Generator Set
kw	kva	pf phase
voltage		amps
duty		overload
rpm		hz
class of insul	ation	pmg voltage
field amp max	<u> </u>	field voltage max
generator mode	1_no	
voltage regula	tor model no	
ID no.		
generator set	serial no.	
BS5000		NEMA



REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
1	191-1876	3011292	1	Guard, Belt - Alternator Attaching Parts for Guard
	815-0714	3013904	3	Screw, Cap - Hex Head with Washer (1/4-20 x 7/16")
	526-0359	146159	3 3	Washer, Flat (1/4")
2	511-0161	206996	1	Belt, Drive - Multi Grave
3	130-3254	3002323	1	Pulley - Multi Grove
4	800-0215	\$113	1	Screw, Cap - Hex Head (1/2-13 x 1-1/2")
5	800-0236	\$106	1	Screw, Cap - Hex Head (1/2-13 x 1-3/4")
6	850-0110	111445	2	Washer, Lock - Spring (1/2")
7	526-0353	203310	4	Washer, Flat (1/2")
	191-1879	3201188	1	Link Assembly - Adjusting
8 9		3201186	1	Bolt, Eye (1/2-20 Left Hand Thread)
10		206202	1	Nut, Hex - Jam (1/2-20 Left Hand Thread)
11		3201185	1	Bolt, Eye (1/2-20 Right Hand Thread)
12		S253	1	Nut, Hex - Jam (1/2-20 Right Hand Thread)
13		3201187	1	Adjuster, Link
14	870-0452	70897	1	Nut, Self-locking - Hex (1/2-20)
15	800-0237		1	Screw, Cap - Hex Head $(1/2-20 \times 6-1/2")$
16	191-1846-01	3016627	1	Alternator - 24 VDC, 35 Amp (Less Pulley)

Air Cleaner Indoor







Air Cleaner Indoor

REF	CPS	CEC	QTY	PART
NO.	PART NO.	PART NO.	USED	DESCRIPTION
1	140-2226	178957	1	Indicator, Air Restriction (Includes Fitting)
2	140-1260		1	Fitting, Male - Hex
3	503-1585-11	140313	1	Clamp, Hose - T-Bolt (6-1/8"NON) KT, KTA
4				Clamp, Hose - T-Bolt (7-5/8"NON)
	503-1585-12	140314	1 2	KTA
	503-1585-12	140314	2	KTTA
5				Not Used
6		3018042		Element, Air Cleaner
7	140-2264	4028847	1	Cleaner, Air
8	800-0224	S111	2	Screw, Cap - Hex Head (5/16-18 x 1-1/4")
9	867-0032	69832	2	Nut, Hex (5/16-18)
10	850~0102	S605	2	Washer, Lock - Spring (5/16")
11	140-2222-20	3022322	2	Strap, Mounting - Air Cleaner
				Attaching Parts for Straps
	800-0224	\$111	4	Screw, Cap - Hex Head $(5/16-18 \times 1-1/4")$
	850-0102	S605	4	Washer, Lock - Spring (5/16")
	862-0032	69832	4	Nut, Hex (5/16-18)

Air Cleaner Outdoor







Air Cleaner Outdoor

REF	CPS	CEC	QTY	PART
NO.	PART NO.	PART NO.	USED	DESCRIPTION
1	140-2226	178957	1	Indicator, Air Restriction (Includes Fitting)
2	140-1260		1	Fitting, Male - Hex
3	503-1585-11	140313	1	Clamp, Hose - T-Bolt (6-1/8"NON) KT, KTA
4				Clamp, Hose - T-Bolt (7-5/8"NON)
	503-1585-12	140314	1	KTA
	503-1585-12	140314	2	KTTA
5		3017003	1	Cap, Air Cleaner
6		3018042		Element, Air Cleaner
7		3017002	1	Cleaner, Air
8	800~0224	S111	2	Screw, Cap - Hex Head (5/16-18 x 1-1/4")
9	867-0032	69832	2 2	Nut, Hex (5/16-18)
10	850-0102	\$605	2	Washer, Lock - Spring (5/16")
11	140-2222-20	3022322	2	Strap, Mounting - Air Cleaner
				Attaching Parts for Straps
	800-0224	S111	4	Screw, Cap - Hex Head $(5/16-18 \times 1-1/4")$
	850-0102	S605	4	Washer, Lock - Spring (5/16")
	862-0032	69832	4	Nut, Hex (5/16-18)

Air Cleaner Heavy Duty






Air Cleaner Heavy Duty

REF	CPS	CEC	QTY	PART
NO.	PART NO.	PART NO.	USED	DESCRIPTION
1	140-2226	178957	1	Indicator, Air Restriction (Includes Fitting)
2	140-1260		1	Fitting, Male - Hex
3	503-1585-11	140313	1	Clamp, Hose - T-Bolt (6-1/8"NON) KT, KTA
4				Clamp, Hose - T-Bolt (7-5/8"NON)
	503-1585-12	140314	1	KTA
	503-1585-12	140314	2	KTTA
5	140-1545	3013238	1	Cap, Air Cleaner
6		3060220	1	Element, Primary - Air Cleaner
6 7		3060221	1	Element, Secondary - Air Cleaner
8	140-2301	3056713	1	Cleaner, Air
9	800-0224	\$111	2	Screw, Cap - Hex Head (5/16-18 x 1-1/4")
10	867-0032	69832	2	Nut, Hex (5/16-18)
11	850-0102	S605	2	Washer, Lock - Spring (5/16")
12	140-2222-20	3022322	2	Strap, Mounting - Air Cleaner
				Attaching Parts for Straps
	800-0224	S111	4	Screw, Cap - Hex Head (5/16-18 x 1-1/4")
	850-0102	S605	4	Washer, Lock - Spring (5/16")
	862-0032	69832	4	Nut, Hex (5/16-18)

External Engine Components Left Side




External Engine Components Left Side

REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
1	309-0572-02	3048727	1	Switch, Temperature - Engine Coolant
2	309-0570	3034866	1	Switch, Temperarure - Engine Coolant
3	302-1854	3015238	1	Transducer (Sender), Temperature - Engine Coolant
4				*Filter, Water - W/Corosion Inhibiting Chemical DCA4
		3318157	1	20-40 Gal Cooling Systems [WF2070]
		3315116	1	40-60 Gal Cooling Systems [WF2071]
		3318201	1	60-90 Gal Cooling Systems [WF2072]
		3315115	1	90-UP Gal Cooling Systems [WF2073]
5				Heater, Oil - 300 Watt
	333-0407-02	167619	1	120 VAC
	333-0407-04	167621	1	240 VAC
	333-0407-05	3000214	1	480 VAC
6	337-2401-03	3018924	1	Lead, Electrical - Ground
7	337-2407-01	41790	1	Cable, Battery - Negative
8	416-0473		1	Cable, Battery - Jumper
9	337-2407-02	119573	1	Cable, Battery - Positive
10				Starter, 24 VDC
		205431	1	Standard
	191-1588		1	Heavy Duty
11	307-2621-02	3050692	1	Switch, Magnetic
12	122-0526	3313283	1	Filter, Oil - Bypass [LF777]

^{*} NOTE: Replacement cartridges recommend and should be used in lieu of the Original Engine Factory Installed Item which contains a Pre-Charge amount of DCA or DCA4 Chemical. Replacement with Pre-charge Cartridge may overload the Cooling System and cause problems or failure of the Set.


External Engine Components Right Side



External Engine Components Right Side


REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
1 2	151-0636-01	3034572	1	Pickup, Magnetic with Harness : Switch, Pressure - Oil
	309-0565-01	3034864	1	Standard, 3 Wire Harness
	309-0566	3034863	1	Pre-Alarm System, 4 Wire Harness
3	302-1853	3015237	1	Transducer (Sender), Pressure - 0il
4		3313279	2	Filter, Oil [LF670]
5	302-1854	3015238	1	Transducer (Sender), Temperature - Engine Oil
6		3315847	2	Filter, Fuel - With Orain [FF105D]
7	338-2307	3053030	1	Harness, Wiring - Engine

Fan, Fan Guards




Fan, Fan Guards

REF	CPS	CEC	QTY	PART
NO.	PART NO.	PART NO.	ÜSED	DESCRIPTION
1	130-3258	3011291	2	Guard, Fan - Side
2	130-3260	3021669	1	Guard, Fan - Top & Rear, Left Side
3	130-3259	3021668	1	Guard, Fan - Top & Rear, Right Side
4	511-0162	3002203	1	Belt, Drive - Fan
5	130-3263	3037710	1	Fan, Cooling - Pusher
6	130-3265	3045665	1	Spacer, Fan
7	130-3251-01	3001346	2	Brace
8	130-3250	3001347	2	Bracket, Upper - Radiator Support
9	130-3256	3003717	2	Bracket, Lower - Radiator Support
10	130-3266	3050389	1	Shroud, Fan



Cooling System - Radiator

REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
NO.	PART NO.	PART NO.	OGED	DESCRIPTION
1	501-0537-06	AS5033SS	1	Hose Assembly, Fuel
2	502-1045-12	143950	2	Connector, Pipe
3	503-1586	43828d	8	Clamp, Hose
4	503-1617	67369C	2	Hose $(2-1/2"ID \times 3"LG)$
5	503-1614	67369	2	Hose $(2-1/2"IF \times 4"LG)$
2 3 4 5 6 7 8 9	130-3261-01	3001356	2 8 2 2 2 1 3 1 1 1 1 4 2 1 2	Tube, Water - Upper
7	503-1585~01	125739	1	Clamp, Hose - T-Bolt
8	503-1585-13	140315	3	Clamp, Hose - T-Bolt
9	503-1615	60985	1	Hose $(3-1/2"ID \times 3-1/2"LG)$
10	503-1613	64978	1	Hose $(3-1/2"ID \times 5"LG)$
11	504-0028	107947	1	Cock, Drain
	505-1381		1	Bushing, Reducer - Hex
13	130-3264-01	3004245	1	Tube, Water - Lower
14	503-1603	42828A	4	Clamp, Hose
15	503-1616	200517	2	Hose $\{1^{\text{"ID}} \times 3^{\text{"LG}}\}$
	130-3267		1	Tube, Water - Fill
17	505-1383	S901	2	Plug, Pipe
18	338-2319	3026825	1.	Harness, Wiring - Coolant Switch
19	309-0579-03	3046031	1	Switch, Low Coolant Level
	130-0523		1	Cap, Radiator - 7 Lb
21				Radiator (Includes Front Guards)
	130-3249-04	3050217	1	KT, KTA Standard (100°C)
	130-3249-05	3050218	1	KT, KTA Hi Ambient (125°C)
	130-3249-05	3050218	1 1 1	KTTA Standard (100°C)
	130-3249-06	3050329	1	KTTA Hi Ambient (125°C)



Heater - Engine Coolant

```
REF
       CPS
                     CEC
                                  OTY
                                               PART
                                            DESCRIPTION
                     PART NO.
                                  ÙSED
NO.
       PART NO.
                                            Hose Assembly - Oil Pressure
Elbow, Pipe - Male, 90 DEG
       501-0537-07 AS4050SS
       502-1043-08 112105
                                            Clamp, Hose
Hose, Rubber
       503-1603
503-1602
                                   8
 3
                     43828A
                     3027706
 4
                                    3
       503-1604
                     170049
                                    1
                                            Elbow, Hose - Rubber
                                            Coupling, Hose - Elbow, 45 DEG
 6
       502-1049
                     152546
 8
       130-3269
                     3058373
                                    1
                                            Tube, Water
       130-3268
                     3056693
                                   1
                                            Tube, Water
                                            Heater, Electrical - Engine Coolant (Includes Thermostat,
11
                                             Oil Pressure Switch, Drain Cock and Mounting Nuts)
                                               4000 Watt, 208 VAC
       333-0413-08 3063473
                                    1
       333-0389-02 3056182
                                    1
                                              4000 Watt, 240 VAC
                                              4000 Watt, 480 VAC (Includes Heater Control Switch Unit)
4000 Watt, 120 VAC (Includes Heater Control Switch Unit)
       333-0389-04 3056184
       333-0389-06 3053979
                                    1
                                            Attaching Parts for Heater
                                              Screw, Cap - Hex Head (1/4-20 \times 3/4") Washer, lock - Spring (1/4")
       800-0222
                     S114
       850-0101
                     S600
       402~0608
                                              Isolator, Vibration
                     3035083
                                            Isolator, Vibration
Nut, Special(Supplied with Heater)
       402-0609
                     3035084
                                    2
12
                                            Cock, Drain (1/4 NPT)
13
       504-0003
                                    1
14
                     3059903
                                            Thermostat
                     3059904
                                            Switch, Pressure - 0il
15
                                    1
                                            Bracket, Mounting - Heater
16
       130-3189
                     3056255
                                    1
                                            Attaching Parts for Bracket
                                              Screw, Cap - Hex Head (3/8-16 \times 1-1/4") Washer, lock - Spring (3/8")
                                    4
       800-0210
                     S1030
       850-0103
                     S604
                                              Nut. Hex - Brass (3/8-16)
       871-0028
                     S254
                                    4
                                            Switch, Control - Heater (Includes Contactor, Step-down
17
                                               Transformer with Fuse[480V Unit Only], Ground Lug and Box)
       309-0567-01 3056188
                                               120 VAC
                                    1
       309-0567-02 3056189
                                    1
                                               480 VAC
                                            Attaching Parts for Switch Screw, Cap - Hex Head (1/4-20 \times 3/4")
       800-0222
                     S114
                                               Washer, lock - Spring (1/4")
       850-0101
                     $600
                                               Nut, Hex (1/4-20)
       862-0031
                     S224
18
                                            Contactor (37.5 AMP, 3 Pole, SPST, 120 VAC Coil)
                                            Fuse (1 AMP)
19
                                    1
                                            Transformer, Step-down (240/480VAC Primary, 120 VAC
20
                                    1
                                               Secondary, with Fuse Clips on output Terminals)
21
                                    1
                                            Box, Electrical
       333-0390
                                            Bracket, Mounting - Switch (Not Illustrated)
22
                                            Attaching Parts for Bracket
                                              Screw, Cap - Hex Head (3/8-16 \times 1-1/4") Washer, lock - Spring (3/8")
                     S103D
       800-0210
       850-0103
                     5604
       871-0028
                                    2
                                               Nut, Hex - Brass (3/8-16)
                     S254
```

GENERATOR SECTION


Table of Contents

Blank for	Notes.,	3 2
Generator	Size Table	33
Generators	s SAE0/SAE18	3 5
Generator	Stator Section [Frame Size 4]	37
Generator	Stator Section [Frame Size 5]	3 9
Generator	Stator Section [Frame Size 6]	4 1
Generator	Rotor Section [Frame Size 4, SAE0/SAE18]	43
Generator	Rotor Section [Frame Size 5, SAEO/SAE18]	4.5
Generator	Rotor Section [FRame Size 6, SAEO/SAE18]	47
Permanent	Magnet Exciter	4.8

GENERATOR TABLE

	,	,		,	,		OL TAGE		HERTZ			26 TES	* - · · ·
OPTION CODE	FRAME SIZE	ADPTR SAE	DISK SAE	LEAD	kW RATING	380 190	416 208	440 220	460 230	480 240	380 190	50 HER 400 200	416 208
MG8310	4 E	0	18	12	Standby Prime	290 275	305 280	315 290	325 300	335 305	255 235	260 240	270 245
MG8311	4 F	0	18	12	Standby Prime Pwr	340 310	350 320	360 330	370 340	380 350	280 265	290 270	300 275
MG8316	5 C	0	18	12	Standby Prime Pwr	400 370	420 385	440 400	465 425	475 430	355 325	36 5 330	375 335
MG8317	5 D	0	18	12	Standby Prime	425 390	450 410	475 430	500 450	515 470	400 360	410 375	425 385
MG8318	5 E	0	18	12	Standby Prime Pwr	515 480	545 500	570 520	585 530	600 540	460 420	475 435	490 450
MG8319	5 F	0	18	12	Standby Prime Pwr	570 525	590 550	620 570	635 580	650 590	500 450	515 465	530 480
MG8320	6 AS	0	18	6	Standby Prime Pwr	610 575	640 600	660 625	680 640	700 650	540 500	550 515	570 525
MG8321	6 A	0	18	6	Standby Prime	670 625	700 650	740 675	770 710	800 730	610 555	630 580	650 600
MG8322	6 8	0	18	6	Standby Prime Pwr	750 680	800 730	830 770	860 800	900 820	680 620	700 640	720 660
MG8323	6 C	0	18	6	Standby Prime Pwr	880 820	920 850	960 880	1000 920	1050 950	800 730	825 750	840 765
MG8324	6 D	0	18	6	Standby Prime Pwr	950 880	1000 950	1050 990	1100 1020	1150 1050	875 800	900 825	920 850
MG8326	6 A	0	18	12	Standby Prime Pwr	670 625	700 650	740 675	770 710	800 730	610 555	630 580	650 600
MG8327	6 B	0	18	12	Standby Prime Pwr	750 680	800 730	830 770	860 800	900 820	680 620	700 640	720 6 60
MG8328	6 C	0	18	12	Standby Prime Pwr	880 820	920 850	960 880	1000 920	1050 950	800 730	825 750	840 765
MG8329	6 D	0	18	12	Standby Prime	950 880	1000 950	1050 990	1100 1020	1150 1050	875 800	900 825	920 850

Generators SAE 0 / SAE 18




Generators SAE 0 / SAE 18

REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
1			1	Module, Permanent Magnet Exciter (See Separate Page for Components) Attaching Parts For Module
	249-0298		4	Screw, Cap - Hex Head (M8 x 16mm)
	249-0218		4	Washer, Lock (M8)
	249-0315		4	Clamp, Retaining
2	Note 1			Generator [Includes PMG Exciter)
				(See Separate Pages for Stator and Rotor Components)
				Attaching Parts Generator To Skid
				Frames 4 and 5
	800-0240	138148	2	Screw, Cap - Hex Head (7/8-9 x 5")
	850-0108	S612	2	Washer, Lock - Spring (7/8")
	526-0348	S640	4	Washer, Flat (3/4")
	370-4045	3052064	2	Spacer
	862-0036	S203	2	Nut, Hex (7/8-9)
				Frame 6
	800-0242	S161	2	Screw, Cap - Hex Head (1-8 x 3-1/2")
	850-0109	S613	2	Washer, Lock - Spring (1")
	526-0360	146180	4	Washer, Flat (1")
	862-0037	\$222	2	Nut, Hex (1-8)
				Attaching Parts Adapter to Flywheel Housing Frame 4
	800-0238	S145	2 .	Screw, Cap - Hex Head (1/2-13 x 1-1/4")
	800-0236	S106	14	Screw, Cap - Hex Head (1/2-13 x 1-3/4")
	850-0105	\$608	16	Washer, Lock - Spring (1/2")
				Frame 5
	800-0215	\$113	8	Screw, Cap - Hex Head (1/2-13 x 1-1/2")
	800-0216	S125	4	Screw, Cap - Hex Head (1/2-13 x 2")
	850-01 05	\$608	12	Washer, Lock - Spring (1/2")
				Frame 6
	800-0238	S145	2	Screw, Cap - Hex Head (1/2-13 x 1-1/4")
	800-0236	S106	14	Screw, Cap - Hex Head (1/2-13 x 1-3/4")
	850-0105	S608	16	Washer, Lock - Spring (1/2")
				Attaching Parts Drive Disc to Flywheel
	815-0719	206332	6	Screw, Cap - 12 Point Drive (5/8-11 x 1-1/4")
	526-0362	200861	6	Washer, Flat (5/8")

Note 1: For replacement Generator please supply the complete Gen Set nameplate and Generator nameplate data.


Generator Stator Section Frame 4



Generator Stator Section Frame 4

REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
1	NFS		1	Lid
2	NFS		2	Panel, Side
3	NFS		ī	Panel, Front
4	NFS		ī	Panel, Rear
5	NFS		2	Bracket, Angle
6	249-0631		2	Lid, Electrical Box - Plain
·	243 0001		-	Attaching Parts
	249-0304		8	Screw, Captive
7	243 0004		Ū	Regulator, Voltage
'	305-0770		1	Standard 1 Phase
	305-0778		ī	3 Phase (Used with 3 Phase Sensing Module)
	305-0803		î	Manual
	303 0003		-	Attaching Parts
	249-0398		4	Pillar, Threaded
8	300-3278		1	Module, 3 Phase Sensing
٥	300-3210		_	Attaching Parts
	249-0398		4	Pillar, Threaded
9	249-0395		2	Box, Electrical
10	249-0395		i	Module, Overvoltage
10	245 0400		•.	Attaching Parts
	240-0206		4	Screw, Cap - Hex Head (M5 x 35mm)
	249-0295		. 4	
	249-0288			Washer, Plastic (M5) Nut, Hex - Nylon (M5)
11	249-0287		1	Switch
12	249-0449		1	RFI Suppressor Assy
13	249-0569		1	Choke
	302-1851		1	
14	354-0031		3	Resistor, Adjustable
15 16	249-0504		3	Transformer, Voltage Sensing Block, Terminal
	249-0289		1	Panel, Terminal Block Mounting
17 18	249-0424	•	3	
19	302-1852-02	•	2	Transformer, Current Grille, Inlet - Air
	249~0438		4	
20	249-0243		4	Screw, Cap - Hex Head (M10 x 30mm)
21	249-0202		. 1	Washer, Lock - Spring (M10)
22 23	249-0242		1	Cap, Bearing - Outer Circlip
23	249-0232		8	Screw, Cap - Hex Head (M10 x 35mm)
25	249-0201		8	Washer, Lock - Spring (M10)
26	249-0202 249-0241		1	Bearing, Ball
27	249-0241		4	Screw, Cap - Hex Head (M10 x 50mm)
28	249-0202		4	Washer, Lock - Spring (M10)
29	249-0244		ī	Cap, Bearing - Inner
30	249-0256		6	Screw, Cap - Hex Head (M6 x 65mm)
31	249-0212		6	Washer, Lock - Spring (M6)
32	249-0255		ĭ	Stator, Exciter
33	249-0200		ī	Bracket, End
34	NFS		î	Stator, Generator (Includes Terminal Studs and Links)
0 -4	14, 0		-	Attaching Parts Stator to Adapter
	249-0204		8	Screw, Cap - Hex Head (M12 x 40mm)
	249-0205		8	Washer, Lock - Spring (M12)
35	249-0200		4	Link, Terminal
36	742 ATAA		•	Heater, Electrical - Replacement
-	249-0621		1	70 Watt, 120 VAC
	249-0622		ī	70 Watt, 240 VAC
	7-0 OOEE		-	recreased the reserve


Generator Stator Section Frame 5



Generator Stator Section Frame 5


REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
1	NFS		1	Lid
2	NFS		2	Panel, Side
3	NFS		1.	Panel, Front
4	NFS		1.	Panel, Rear
5	NFS		2	Bracket, Angle
6	249~0631		2	Lid, Electrical Box - Plain
				Attaching Parts
	249-0304		8	Screw, Captive
7				Regulator, Voltage
	305-0770		1	Standard 1 Phase
	305-0778		1	3 Phase (Used with 3 Phase Sensing Module)
	305~0803		1	Manual
				Attaching Parts
	249~0398		4	Pillar, Threaded
8	300-3278		1 .	Module, 3 Phase Sensing
-	• • • • • • • • • • • • • • • • • • • •			Attaching Parts
	249-0398		4	Pillar, Threaded
9	249-0395	•	2	Box, Electrical
10	249-0486		1	Module, Overvoltage
				Attaching Parts
	249~0295		4	Screw, Cap - Hex Head (M5 x 35mm)
	249-0288		4	Washer, Plastic (M5)
	249-0287		4	Nut, Hex - Nylon (M5)
11	249-0449		1	Switch
12	249-0569		1	RFI Suppressor Assy
13	302~1851		1 .	Choke
14	354-0031		1	Resistor, Adjustable
15	249-0504		3	Transformer, Voltage Sensing
16	249-0289		3	Block, Terminal
17	249~0424		1	Panel, Terminal Block Mounting
18	302-1852-02		3	Transformer, Current
19	249-0408		2	Grille, Inlet - Air
20	249-0243		4	Screw, Cap - Hex Head (M10 x 30mm)
21	249-0202		4	Washer, Lock - Spring (M10)
22	249~0242		1	Cap, Bearing - Outer
23	249-0232		1	Circlip
24	249-0201		8	Screw, Cap - Hex Head (M10 x 35mm)
25	249-0202		8	Washer, Lock - Spring (M10)
26	249-0241		1	Bearing, Ball
27	249-0245		4	Screw, Cap - Hex Head (M10 x 50mm)
28	249-0202		4	Washer, Lock - Spring (M10)
29	249-0244		1	Cap, Bearing - Inner
30	249-0256		6	Screw, Cap - Hex Head (M6 x 65mm)
31	249-0212		6	Washer, Lock - Spring (M6)
32	249-0255		1	Stator, Exciter
33	249-0272		1	Bracket, End States Community (Includes Terminal Stude and Links)
34	NFS		1	Stator, Generator (Includes Terminal Studs and Links) Attaching Parts Stator to Adapter
	249~0204		8	Screw, Cap - Hex Head (M12 x 40mm)
	249-0205		8	Washer, Lock - Spring (M12)
35			,	Heater, Electrical - Replacement
	249-0621		1	70 Watt, 120 VAC
	249-0622		1	70 Watt, 240 VAC

Generator Stator Section Frame 6




Generator Stator Section Frame 6

REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
1	NFS		1	Lid
2	NFS		2	Panel, Side
3	NFS		1	Panel, Front
4	NFS		1	Panel, Rear
5	NFS		2	Bracket, Angle
6	249-0425		2	Lid
				Attaching Parts
	249-0304		8	Screw, Captive
7	•			Regulator, Voltage
	305-0770		1	Standard
	305-0778		1	3 Phase (Used with 3 Phase Sensing Module)
	305-0803		1	Manua 1
				Attaching Parts
	249-0398		4	Pillar, Threaded
8	302-3278		1	Module, 3 Phase Sensing
				Attaching Parts
	249-0398		4	Pillar, Threaded
9	249-0395		2	Box
10	249-0486		1	Module, Overvoltage
				Attaching Parts
	249-0295		4	Screw, Cap - Hex Head (M5 x 35mm)
	249-0288		4	Washer, Plastic (M5)
	249-0287		4	Nut, Hex - Nylon (M5)
11	249-0449		1	Switch
12	249-0569		1	RFI Suppressor Assy
13	302-1851		1	Choke
14	354-0031		1	Resistor, Adjustable
15	249-0504		3 3	Transformer, Voltage Sensing
16	249-0289		1	Block, Terminal
17 18	249-0424		3	Panel, Terminal Block Mounting
19	302-1852-02		2	Transformer, Current
20	249-0513		4	Grille, Inlet - Air
21	249-0243 249-0202		4	Screw, Cap - Hex Head (M10 x 30mm) Washer, Lock - Spring (M10)
22	249-0510		1	Cap, Bearing - Outer
23	249-0447		î	Circlip
24	249-0204		8	Screw, Cap - Hex Head (M12 x 40mm)
25	249-0205		8	Washer, Lock - Spring (M12)
26	249-0448		ĭ	Bearing, Ball
27	249-0245		4	Screw, Cap - Hex Head (M10 x 50mm)
28	249-0202		4	Washer, Lock - Spring (M10)
29	249-0509		1	Cap, Bearing - Inner
30	249-0445		6	Screw, Cap - Hex Head (M6 x 85mm)
31	249-0212		6	Washer, Lock - Spring (M6)
32	249-0470		1	Stator, Exciter
33	249-0527		1	Bracket, End
34	NFS		1	Stator, Generator (Includes Terminal Studs and Links)
				Attaching Parts Stator to Adapter
	249-0204		8	Screw, Cap - Hex Head (M12 x 40mm)
	249-0205		8	Washer, Lock - Spring (M12)
35				Heater, Electrical - Replacement
	249-0621		1	70 Watt, 120 VAC
	249-0622		1	70 Watt, 240 VAC



Generator Rotor Section SAE 0/ SAE 18 Frame 4


REF	CPS	CEC	QTY	PART
NO.	PART NO.	PART NO.	USED	DESCRIPTION
1	249-0311		2	Screen, Air - Adapter Attaching Parts
	249-0294		12	Screw, Cap - Hex Head (M5 x 12mm)
	249-0307		12	Washer, Lock - Spring (M5)
	249-0365		12	Washer, Flat (M5)
2	249-0435		1	Adapter, Generator SAE 0
3	249-0231		8	Screw, Cap - Hex Head (M20 x 50mm)
4	249-0230		1	Plate, Pressure
5	249-0276		5	Disc, Drive SAE 18
7	NFS		1	Rotor, Generator (Includes Exciter, Key, and Rectifier Assy)
8	249-0321		1	Rotor, Exciter (Does Not Include Rectifier Assy)
9	249-0271		1	Key
10	249-0237		1	Rectifier Assy (Includes Diodes)
11	249-0239		3	Diode, Forward Polarity
12	249-0238		3	Diode, Reverse Polarity
13	249-0240		1	Varister



Generator Rotor Section SAE 0/ SAE 18 Frame 5

REF	CPS	CEC	QTY	PART
NO.	PART NO.	PART NO.	USED	DESCRIPTION
1	249-0408		2	Screen, Air – Adapter Attaching Parts
	249-0294		12	Screw, Cap - Hex Head (M5 x 12mm)
	249-0307		12	Washer, Lock - Spring (M5)
	249-0365		12	Washer, Flat (M5)
2	249-0322		1	Adapter, Generator SAE 0
3	249-0437		8	Screw, Cap - Hex Head (M20 x 75mm)
4	249-0230		1	Plate, Pressure
5	249-0276		4	Disc, Orive SAE 18
6	249-0277		1	Spacer
7	NFS		1	Rotor, Generator (Includes Exciter, Key, and Rectifier Assy)
8	249-0522		1	Rotor, Exciter (Does Not Include Rectifier Assy)
9	249-0271		1	Key
10	249-0237		1	Rectifier Assy (Includes Diodes)
11	249-0239		3	Diode, Forward Polarity
12	249-0238		3	Diode, Reverse Polarity
13	249-0240		1	Varister

NFS - Not For Sale




Generator Rotor Section SAE 0/ SAE 18 Frame 6

REF	CPS	CEC	QTY	PART
NO.	PART NO.	PART NO.	USED	DESCRIPTION
1	249-0534		2	Screen, Air - Adapter Attaching Parts
	249-0294		12	Screw, Cap - Hex Head (M5 $ imes$ 12mm)
	249-0307		12	Washer, Lock - Spring (M5)
	249-0365		12	Washer, Flat (M5)
2	249-0533		1	Adapter, Generator SAE 0
3	249-0437		8	Screw, Cap - Hex Head (M20 x 75mm)
4	249~0230		1	Plate, Pressure
5	249-0276		6	Disc, Drive SAE 18
6	249-0277		1	Spacer
7	NFS		1	Rotor, Generator (Includes Exciter, Key, and Rectifier Assy)
8	249-0512		1	Rotor, Exciter (Does Not Include Rectifier Assy)
9			1	Key
10	249-0237		1	Rectifier Assy (Includes Diodes)
11	249-0239		3	Diode, Forward Polarity
12	249-0238		3	Diode, Reverse Polarity
13	249-0240		1	Varister

NFS - Not For Sale

Generator Permanent Magnet Exciter




REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
_				
1	249-0497		T	Cover, Permament Magnet
				Attaching Parts For Cover
	249-0294		3	Screw, Cap - Hex Head (M5 x 12mm)
	249-0307		3	Washer, Lock (M5)
2	249~0496		3	Pillar, Threaded
3	249-0426		1	Stator Assembly with Frame
	249-0427		1	•
			ī	
			-	
	249-0399		1	
			1	
			Ť.	
5	249-0313		1	Pin, Dowel
2 3 4 5	249-0307 249-0496		3 3	Washer, Lock (M5)

CONTROL SECTION

TABLE OF CONTENTS


Control,	Generator Set	53
Control P	Panel, Generator (Sets with LED Indicator Lights)	5 5
Control P	Panel, Generator (Sets with Bulb Indicator Lights)	57
Control P	anel, Engine (Sets with LED Indicator Lights)	59
Control P	anel, Engine (Sets with Bulb Indicator Lights)	6 1
Control W	liring Harnesses (Sets with LED Indicator Lights) (63
Control W	liring Harnesses (Sets with Bulb Indicator Lights) (65
Control I	nternal Components (Sets with LED Ind Lights)	6 6
Control I	nternal Components (Sets with Bulb Ind Lights)	67
Control A	larm Module	68



Generator Set Control

REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
1	NFS	NFS	1	Control, Generator Set (See Items 3 Thru 5 for Components) Attaching Parts for Control
	862-1001	70299	8	Nut, Hex (1/4-20)
	850-1040	70189	8	Washer, Lock - Spring (1/4")
2	NFS	NFS	ĭ	Cover, Control
-	.,, •	•	<u> </u>	Attaching Part for Cover
	815~0701	3016086	6	Screw, Machine - Round Head (1/4-20 x 1/2")
3	NFS	NFS	1	Control Panel, Generator (See Separate Pages for Components)
4	NFS	NFS	ī	Control Panel, Engine (See Separate Pages for Components)
5	NFS	NFS	1	Internal Components and Wiring Harnesses (See Separate Pages Selection)
6	337-2402	3016849	1	Lead, Electrical - Ground
7	402-0610	204493	4	Mount, Vibration
8				Transformer, Current (Select as Required)
_	302-1866-05	3011674	3	400:5 Ratio (Used with 200/400 AMP Ammeter)
	302-1866-09			600:5 Ratio (Used with 300/600 AMP Ammeter)
	302-1866-13		3	800:5 Ratio (Used with 400/800 AMP Ammeter)
	302-1866-15		3 3 3 3	1000:5 Ratio (Used with 500/1000 AMP Ammeter)
	302-1866-17		š	1200:5 Ratio (Used with 600/1200 AMP Ammeter and 1200 AMP
			_	Single Scale Ammeter)
	302-1866-21	3011690	3	1600:5 Ratio (Used with 800/1600 AMP Ammeter)
	302-1866-24		3 3 3 3	2000:5 Ratio (Used with 1000/2000 AMP Ammeter)
	302-1866-27		3	2500:5 Ratio (Used with 2500 AMP Single Scale Ammeter)
	302-1866-28		3	3000:5 Ratio (Used with 1500/3000 AMP & 3000 AMP Single
			=	Scale Ammeters)


Generator Control Panel With L E D Indicator Lights



Generator Control Panel With L E D Indicator Lights

```
QTY
                                             PART
REF
       CPS
                    CEC
NO.
       PART NO.
                    PART NO.
                                 USED
                                         DESCRIPTION
 1
                                          Harness, Wiring (See Separate Pages for Selection
                                            and Applications)
 2
       812-0075
                                          Screw, Machine - Round Head (#8-32 x 1/4")
       306-3523
 3
                                          Shield, Switch
                                         Decal (Warning)
 4
       98-5387
                                  1
 5
      870-0437
                                  7
                                         Nut, Acorn - Plastic
       306-3522
                                          Shield, Meters
      870-0451
 7
                    70646
                                         Nut, Self-locking - Hex (#8-32)
 8
       300-3283
                    3053064
                                         Printed Circuit Board - 10 LED Lights
                                         Printed Circuit Board - 4 LED Lights
Printed Circuit Board - 2 LED Lights
                    3053063
       300-3282
                                  1
       300-3281
                    3053062
10
                                  1
                                         Switch, Toggle
11
                    3015057
                                            (AUTOSTART ON/OFF/STANDBY)
                                  1
                    3015058
                                            (SYNCHRONIZING)
                                         Switch, Toggle (ALARM SILENCE)
Switch, Toggle (PANEL LIGHTS)
12
                    3055738
                                  1
13
                    3035149
                                         Light, Panel (Less Bulb)
Bulb, Incandescent
14
       322-0398
                    3035016
                                  2
      322-0397-01 3035018
15
                    3056064
                                         Lens, Clear (SYNCHRONIZING)
16
                                 2
17
                    3056065
                                         Bulb, Incandescent
                                 2
                                         Socket, Light
Switch, Selector(Includes Knob)
19
                    3056063
                    3015860
19
      308-0884
                                 1
      303-0288
20
                    3058451
                                         Rheastat
      302-1860
                    3056071
                                         Wattmeter
21
                                 1
22
                                         Meter (TYPICAL)
      302-1856
                    3015043
                                 1
                                           Voltmeter
                                           Frequency/RPM
      302-1858
                    3015044
                                  1
                                           Ammeter (Select as Required)
DUAL SCALE
                                              200/400 AMP
      302-1871-05 3039530
      302~1862
                    3015035
                                              300/600 AMP
                                              400/800 AMP
      302-1863
                    3015036
                                 1
      302-1871-06 3051478
                                              500/1000 AMP
      302-1864
                    3015037
                                 1
                                              600/1200 AMP
      302-1865
                                              800/1600 AMP
                    3015038
                                 1
      302-1871-01 3015039
                                              1000/2000 AMP
      302-1871-09 3059965
                                              1500/3000 AMP
                                 1
      302-1871-10 3059966
                                              2000/4000 AMP
                                             SINGLE SCALE
      302-1871-02 3015040
                                              1200 AMP
                                 1
      302-1871-03 3015041
                                              1600 AMP
                                 1
                                              2000 AMP
      302-1871-04 3015042
                                 1
      302-1871-07 3051479
                                              2500 AMP
      302-1871-08 3051480
                                              3000 AMP
```


Generator Control Panel With Bulb Indicator Lights



Generator Control Panel With Bulb Indicator Lights

REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
1				Harness, Wiring (See Separate Pages for Selection and Applications)
2	812-0075		2	Screw, Machine - Round Head (#8-32 x 1/4")
3	306-3523		1	Shield, Switch
4	98-5387		1	Decal (Warning)
5	870-0437		7	Nut, Acorn - Plastic
6	306-3522		1 .	Shield, Meters
7				Lens, Indicator Light
		3018795	4	Orange
		3018796	1	Red
		3018797	1	Green
		3018798	2	White (SYNCHRONIZING)
8		3018799	8	Bulb, Incandescent
9			_	Socket & Socket with Switch
		3018800	7	Socket, Light
		3014667	1	Socket, Light with Push Switch
10		3015133	2	Light, Indicator - Red Lens (UPPER/LOWER SCALE INDICATING)
11				Switch, Toggle
		3015057	1	(AUTOSTART-ON/OFF/STANDBY)
		3015058	1	(SYNCHRONIZING)
12		3055738	1	Switch, Toggle (ALARM SILENCE)
13		3035149	1	Switch, Toggle (PANEL LIGHTS)
14	322-0398	3035016	2	Light, Panel (Less Bulb)
15	322-0397-01		2	Bulb, Incandescent
16		3015018	1	Wattmeter
17	444 4454	2015040		Meter
	302-1856	3015043	1	Voltmeter
	302-1858	3015044	1	Frequency/RPM Ammeter (Select as Required) DUAL SCALE
	302-1871-05	3039530	1	200/400 AMP
	302-1862	3015035	1	300/600 AMP
	302-1863	3015036	1	400/800 AMP
	302-1871-06	3051478	1	500/1000 AMP
	302-1864	3015037	1	600/1200 AMP
	302-1865	3015038	1	800/1600 AMP
	302-1871-01	3015039	1	1000/2000 AMP
	302-1871-09	3059965	1	1500/3000 AMP
	302-1871-10	3059966	1	2000/4000 AMP
				SINGLE SCALE
	302-1871-02	3015040	1	1200 AMP
	302-1871-03		1	1600 AMP
	302-1871-04	3015042	1	2000 AMP
	302-1871-07		1	2500 AMP
	302-1871-08		1	3000 AMP
18	308-0884	3015860	1	Switch, Selector(Includes Knob)
19	303-0288	3058451	1	Rheostat


Engine Control Panel With L E D Indicator Lights



Engine Control Panel With L E D Indicator Lights

REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
1	338-2252	3053044	1	Harness, Wiring (Includes items 2 & 3)
2		3055486	1	Switch, Toggle (CRANK)
3		102057	1	Switch, Toggle (START/RUN/OFF)
4	870-0451	70646	4	Nut, Self-locking - Hex (#8-32)
5	526-0352	128006	4	Washer, Flat (3/16")
6				Printed Circuit Board (Includes Test Lamp Switch)
	300-3279	3053060	1	5 L E D Indicator Lights
	300-3280	3053061	1	8 L E D Indicator Lights
6A		3055488	1	Switch, Toggle (LAMP TEST)
7		3015055	ī	Switch, Toggle (RAISE/LOWER)
8	303~0290	3015105	1	Potentiometer (SPEED ADJUST)
9	320-1616	3034953	ī	Circuit Breaker
10	308-0885-02		ī	Switch, Toggle (RUN/IDLE)
11	302-1855	3031734	1	Tachometer
12	402 1000	0001104	-	Gauge/Meter
	193-0400-01	3015232	τ .	Gauge, Pressure - Oil
	193-0401-01		1	Gauge, Temperature - Oil
	193-0402-01		î	Gauge, Temperature - Water
	302-1857-01		1	Voltmeter
	302-1859-01		1	Hourmeter
	AAT 1003 AI	0000100	_	וויסטו וווים לבו


Engine Control Panel With Bulb Indicator Lights



Engine Control Panel With Bulb Indicator Lights

REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
110,	PART NO.	PART NO.	OSLD	GCOOKII (10)
1		3035126	1	Harness, Wiring (Includes items 2 & 3)
1 2		3055486	ī	Switch, Toggle (CRANK)
3		102057	1	Switch, Toggle (START/RUN/OFF)
4		3018795	3	Lens, Light (ORANGE)
5		3018799	3	Bulb, Light
6		3018800	3	Socket, Light
7		3015055	1	Switch, Toggle (RAISE/LOWER)
8	303-0290	3015105	1	Potentiometer (SPEED ADJUST)
9	320-1616	3034953	1	Circuit Breaker
10	308-0885-02		1	Switch, Toggle (RUN/IDLE)
11	302-1855		1	Tachometer
12				Gauge or Meter
	193-0400-01	3015232	1	Gauge, Pressure - Oil
	193-0401-01	3015233	1	Gauge, Temperature - Oil
	193-0402-01	3015234	1	Gauge, Temperature - Water
	302-1857-01	3015235	1	Voltmeter
	302-1859-01		1	Hourmeter


Set Control - Wiring Harnesses (Sets With LED Indicator Lights)



Set Control - Wiring Harnesses (Sets With LED Indicator Lights)

REF	CPS	CEC	QTY	PART
NO.	PART NO.	PART NO.	USED	DESCRIPTION
1	338-2255	3053048	1.	Harness, Wiring (PCB TO LED PCB)
2	338-2258	3056066	1	Harness, Wiring (PCB TO WATTMETER)
3	338-2250	3035147	1	Harness, Wiring (PCB TO VOLT/AMP SELECTOR SWITCH)
4	338-2253	3053046	1	Harness, Wiring (PCB TO AC METER)
5	338-2383	3053033	1	Harness, Wiring (PCB TO RESISTORS AND SYNCHRONIZING SWITCH;
				Includes The Resistors and Switch)
6 7		3015058	1	Switch, Toggle (SYNCHRONIZING)
7		3055739	2	Resistor, Wirewound with Mounting Bracket
				Attaching Parts for Resistor
	860-0003	3043636	4	Nut, Hex (#4-40)
	850-0010	3043637	4	Washer, Lock - Spring (#4)
8	338-2312	3056089	2	Harness, Wiring (HIGH/LOW WYE ADAPTER)
9	338-2256	3056061	1	Harness, Wiring (PCB TO PANEL LIGHTS AND SWITCH; Includes The Switch)
10		3035149	1 .	Switch, Toggle (PANEL LIGHTS)
11	338-2248	3035132	ī	Harness Assembly, Wiring (ENGINE CONTROL PCB TO GENERATOR CONTROL PCB)
12				Harness Assembly, Wiring - With Shielded Leads (ENGINE WIRING HARNESS TO ENGINE CONTROL PCB; Select Length as Applicable)
	338-2301-01	3053037	1	5.3 Feet
	338-2301-02	3053038	1	7.3 Feet
	338-2301-03	3053039	1	9.3 Feet
	338-2301-04	3053040	1	11.3 Feet
	338-2301-05	3053041	1	15.3 Feet
	338-2301-06	3053042	1	25.3 Feet
	338-2301-07	3053043	1	50.0 Feet
	338-2301-08	3057046	1	1.3 Feet
13	331-0525	204494	1	Gasket, Conduit


Set Control - Wiring Harnesses (Sets With Bulb Indicator Lights)




Set Control - Wiring Harnesses (Sets With Bulb Indicator Lights)


REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
1		3035145	1	Harness, Wiring (PCB TO HORN, SWITCH AND INDICATOR LIGHTS; Includes The Horn and Switch)
2		3015118	1	Horn, Electrical - 24 VDC
2 3		3015056	1	Switch, Toggle (ALARM SILENCE)
4		3035142	1	Harness, Wiring (PCB TO WATT TRANSDUCER)
4 5	338-2250	3035147	1	Harness, Wiring (PCB TO VOLT/AMP SELECTOR SWITCH)
6		3035144	1	Harness, Wiring (PCB TO AC METER AND RED INDICATOR LIGHTS; Includes Red Indicator Lights)
7		3035146	1	Harness, Wiring (PCB TO RESISTORS, SYNCHRONIZING LIGHTS AND SWITCH; Includes The Resistors and Switch)
8		3015058	1	Switch, Toggle (SYNCHRONIZING)
9		3015109	2	Resistor, Wirewound with Mounting Bracket Attaching Parts for Resistor
	860-0003	3043636	4	Nut, Hex (#\$-40)
	850-0010	3043637	4	Washer, Lock - Spring (#4)
10	338-2249	3035140	2	Harness, Wiring (HIGH/LOW WYE ADAPTER)
11	338-2256	3056061	1	Harness, Wiring (PCB TO PANEL LIGHTS AND SWITCH; Includes The Switch)
12		3035149	1	Switch, Toggle (PANEL LIGHTS)
13	338-2248	3035132	1	Harness Assembly, Wiring (ENGINE CONTROL PCB TO GENERATOR CONTROL PCB)
14				Harness Assembly, Wiring (ENGINE WIRING HARNESS TO ENGINE CONTROL PCB; Select Length as Applicable)
	338-2276-01	3035127	1	5.3 Feet
	338-2276-02		1	7.3 Feet
	338-2276-03		1	9.3 Feet
	338-2276-04		ī	11.3 Feet
	338-2276-05		1	15.3 Feet
13	331-0525	204494	ī	Gasket, Conduit

Set Control - Internal Components (Sets With LED Indicator Lights)





Set Control - Alarm Module



REF NO.	CPS PART NO.	CEC PART NO.	QTY USED	PART DESCRIPTION
1 2	338-2257	3056062	1	Harness, Wiring - Alarm Board to Gen Control Board Module, Alarm (Includes PC Board, Horn, Switch and Electrical Leads to Horn, Switch and Generator Terminal Board)
	300-3286	3054296	1	Sets with Four Fault Indicators
	300-3287	3054297	1	Sets with Six Fault Indicators
3				Board, Printed Circuit - Alarm Module (Includes Fuse)
	NFS	NF5	1	Sets with Four Fault Indicators
	NFS	NFS	1	Sets with Six Fault Indicators
				Attaching Parts for Board
	870-0451	70546	4	Nut, Self-locking - Hex (#8-32)
	5 26- 0352	128006	4	Washer, Flat (3/16")
4			1	Fuse
5	333-0405-02	149806	1	Horn, Electrical - 24VDC
6		3055738	1	Switch, Toggle